



Customer Notification



Notification No.: 20150925

Version: 1.0

Page: 1 of 2

Release Date: September 25, 2015

Effective Date: September 25, 2015

Notification Status: Advisory Mandatory Announcement

Classification: Firmware Hardware Policy/Procedure

Description: iVIZION® Intelligent Cash Box (ICB®) Setup – Initialization Process

Hardware: iVIZION® Series Banknote Acceptor

Territory: All

Interface: N/A

Check Sum: N/A

Firmware Version(s): N/A

CRC (seed = 0000): N/A

Conditions:

JCM Engineering has received multiple requests for information on the methods to Enable/Disable the Intelligent Cash Box function on the iVIZION Banknote Validator.

Resolution:

To enable or disable the Intelligent Cash Box (ICB) system on an iVIZION Series Next-Generation Banknote Acceptor Unit, ICB can be initialized using either of the following methods:

Method 1 (using the JCM Tool Suite™ Software Application)

ICB Initialization, Enabling/Disabling ICB and Setting an Asset Number can be completed using the JCM Tool Suite application's Utility function.

To do so:

1. Connect the iVIZION Banknote Acceptor to a PC using a standard USB cable.
2. Open the JCM Tool Suite software application.
3. From the **Service Mode** drop-down menu at the bottom of the screen, click on **Utility**.
4. From the **iVIZION Utility Tool** Primary Screen, click on **2) ICB SETTING**.
5. From the **ICB Function** screen, click the desired button(s) to Enable ICB, Set the EGM Asset Number in the iVIZION, or Disable ICB.

Refer to Section 6 of the iVIZION® Series Operation and Maintenance Manual for details.

Method 2 (using DIP Switch Settings)

Maintaining compatibility with the UBA Validator ICB Setup method, DIP Switch settings on the iVIZION Banknote Acceptor can be used to Enable ICB, Set the Asset Number in the iVIZION, or Disable ICB.

To do so:

1. Remove the iVIZION Transport from the Frame.
2. Set DIP Switches 1, 3 and 8 to ON.
3. Reinstall the iVIZION Transport in the Frame.
The iVIZION Unit activates in ICB Ticket Accept mode.
4. Insert an Enable Ticket and Asset Number Ticket to Enable ICB.
5. Insert a Disable Ticket to Disable ICB.

(continued on reverse)



Customer Notification



Notification No.: 20150925

Version: 1.0

Page: 2 of 2

Release Date: September 25, 2015

Effective Date: September 25, 2015

Notification Status: Advisory Mandatory Announcement

Classification: Firmware Hardware Policy/Procedure

Description: iVIZION® Intelligent Cash Box (ICB®) Setup – Initialization Process

Hardware: iVIZION® Series Banknote Acceptor

Territory: All

Interface: N/A

Check Sum: N/A

Firmware Version(s): N/A

CRC (seed = 0000): N/A

Resolution (continued):

6. Remove the iVIZION Transport and reset the DIP Switches to the Operational position, then reinstall the iVIZION Transport in the Frame.

Refer to Page 14 of the Intelligent Cash Box® (ICB) Training Overview for ICB DIP Switch mode settings.

For information on creating Enable/Disable or Asset Number Tickets or Configuring the iVIZION Banknote Acceptor to use the Intelligent Cash Box (ICB) System, contact JCM Technical Support at (800) 683-7248 or email sales@jcmglobal.com.

Note:

This notification reflects current information available at time of publication. This information is subject to change without notice. Please contact your local JCM Sales Representative or JCM Customer Service for additional information.